

Installation manual

ALONI OPTIMA RONDO THERMOSTATIC RAIN SHOWER SET

Points to note:

1. **Reference:** The product description is intended solely as a reference for installation. Depending on the model, there may be differences between mixer taps.
2. **Working pressure:** 0.1 - 0.5 MPa.
3. **Water temperature:**
 - i. Hot water: 55 - 90 °C (recommended: 55 - 65 °C)
 - ii. Cold water: 5-25 °C (recommended: 5-20 °C)
4. **Suitable heating equipment:** Air heat boiler or electric boiler.
5. **Water pipe connection:** Before installation, ensure that the hot water supply is connected on the left and the cold water supply on the right. Flush the pipes with water for at least 1 minute to prevent blockages and malfunctions of the mixer tap.
6. **Pipe inspection:** Check that the water supply pipes are undamaged. Replace them if necessary.
7. **After installation:** Connect the water supply and check that the connections are properly sealed. Check for any leaks
8. **Ambient temperature:** The installation environment must be above 4°C. At lower temperatures, the mixer tap may deform or freeze.
9. **Waste disposal:** Dispose of waste and packaging material in accordance with applicable local laws and regulations.



